QCS Series HC-49/U-S SMD 2-Pad

Features

- · Suitable for RoHS reflow
- Available for tight stability & extended temperature range

Applications

- Computers, Modems, Microprocessors
- Wireless Applications








General Specifications					
Frequency Range		3.200 to 70.000MHz			
Mode of Oscillation Fundamental		3.200 to 32.768MHz			
	Third Overtone	24.576 to 70.000MHz			
Frenquency Tolerance at 25°C		±10 to ±30ppm (±30ppm standard)			
Frequency Stability over Temperature Range		See Stability vs. Temperature Table			
Storage Temperature		-55 to +125°C			
Aging per Year		±3ppm max.			
Load Capacitance C _L		10 to 32pF and Series Resonance			
Shunt Capacitance C ₀		7.0pF			
Equivalent Series Resistance (ESR)		See ESR Table			
Drive Level		1.0mW max.			
Insulation Resistance (M Ω)		500 at 100Vdc ±15Vdc			


Equivalent Series Resistance (ESR)						
Ω max.	Mode of Operation					
300	Fundamental					
200						
120						
80						
60						
50						
40						
80	Fundamental - Third Overtone					
	Ω max. 300 200 120 80 60 50 40					

Frequency Stability vs. Temperature					
Operating Temperature	±10ppm	±20ppm	±30ppm	±50ppm	±100ppm
-20 to +70°C	0	0	0	0	0
-40 to +85°C	0	0	0	•	0
-40 to +105°C				0	0
-40 to +125°C					0
				•	standard O available



Part N	Part Numbering Guide								
Qantek Code	Package	Nominal Frequency (in MHz)	Vibration Mode	Load Capacitance	Operating Temperature Range	Frequency Tolerance	Frequency Stability	Package Option	Packaging
Q = Qantek	CS = HC-49/U-S SMD 2-Pad	7 digits including the decimal point (f.ie. 12.0000)	F = AT-Fund	S = Series 08 = 8pF 12 = 12pF 18 = 18pF 20 = 20pF etc.	A = -20 to +70°C B = -40 to +85°C C = -40 to +105°C D = -40 to +125°C	1 = ±10ppm 2 = ±20ppm 3 = ±30ppm 5 = ±50ppm 0 = ±100ppm	1 = ±10ppm 2 = ±20ppm 3 = ±30ppm 5 = ±50ppm 0 = ±100ppm	H3 = 3.2mm	M = 250pcs Tape&Reel R = 1000pcs Tape&Reel
Example: QCS12.0000F18B35R bold letters = recommended standard specification									





Marking Code Guide


Contains frequency, Qantek manufacturing code, production code (month and year) and load capacitance.

Month Codes				
January	Α	July	G	
February	В	August	Н	
March	С	September	I	
April	D	October	J	
May	Е	November	К	
June	F	December	L	

Year Codes						
2010	0	2011	1	2012	2	
2013	3	2014	4	2015	5	

Load Capacitance Code in pF					
pF	PN Code	pF	PN Code		
12	Α	20	F		
18	В	22	G		
8	С	30	Н		
10	D	32	I		
16	E	S	S		

Example: First Line: 12.000 (Frequency) Second Line: QA1A (Qantek - January - 2011 - 12 pF)



Environmental Specifications		
Mechanical Shock	MIL-STD-202, Method 213, C	
Vibration	MIL-STD-202, Method 201 & 204	
Thermal Cycle	MIL-STD, Method 1010, B	
Gross Leak	MIL-STD-202, Method 112	
Fine Leak	MIL-STD-202, Method 112	

All specifications are subject to change without notice.

